


Installation Manual

HOFA Ceiling Sail with Screw Hooks

Accessory Parts:

Dowel		4 per set
Screw Hook		8 per set

Mounting Accessories:

Drilling Template:

HOFA PureAkust Segel- Montagehilfe
HOFA PureAkust Sail - Assembling aid

Größe 180 / Size 180
180 x 120 cm

Größe 120 / Size 120
120 x 120 cm

Größe 60 / Size 60
60 x 120 cm

Schablone
drilling template

Montageanleitung: www.hofa-akustik.de/montageanleitungen/
Assembly instructions: www.hofa-akustik.de/en/assembly-instructions/

▶ **HOFA-Akustik**

HOFA-Akustik / Lusshardtstraße 1-3 / D - 76689 Karlsdorf
+49 7251 3472 400

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail / wall sail
Größe 60 / Size 60

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail / wall sail
Größe 120 / Size 120

Bohrung Deckensegel
drill hole ceiling sail
Größe 180 / Size 180

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail / wall sail
Größe 60 / Size 60

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail / wall sail
Größe 60 / Size 60

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail / wall sail
Größe 120 / Size 120

Bohrung Deckensegel
drill hole ceiling sail
Größe 180 / Size 180

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail / wall sail
Größe 60 / Size 60

General Information:



We recommend that two people carry out the installation. Secure fastening and the correct choice of screws and wall plugs always depend on the condition of the wall or ceiling and can only be correctly assessed on site. If in doubt, please consult a tradesperson.



For trouble-free installation, the surface should be as even as possible. Woodchip wallpaper is normally not a problem.




If you have any questions during the installation of the system, please do not hesitate to contact us by phone or e-mail: <https://hofa-akustik.de/en/kontakt/>

Tools and Equipment Required:

- Drilling machine with drill bit
- Drilling template HOFA Wall Sail
- Spirit level/measuring tape
- Depending on the surface (additionally): mounting adhesive for gluing in the dowels


Drilling Template HOFA Wall Sail:

- Depending on the size of the HOFA sail, the template must be rotated and moved. The value can be found on the template.
- Use suitable adhesive material such as strong adhesive tape or adhesive putty to attach the drilling template.
- Assembly is much easier with the help of a second person




Mounting Steps for Installation

1. Position the drilling template




Place the template on the corners of the HOFA Ceiling Sail as shown above and mark the drilling points. Repeat the step for the opposite points of the Ceiling Sail.

2. Screw hooks into sails




Now screw the screw hooks into the marked drill points so that the hooks in the sail all point in the same direction.

3. Attach the template to the ceiling



With a second person, attach the drilling template to the ceiling with some tape or adhesive putty. Then mark the first drilling points and draw a guide line on the lower edge.

4. Rotate the template



Rotate the template for the drilling points on the opposite half.

For Ceiling Sail 180: the distance is 60 cm. Secure it in the new position and mark the last drilling points.

5. Drilling and setting hooks



Now drill holes and insert suitable dowels.
Then screw the screw hooks into the dowels.
The screw hooks should all point in one
direction so that the Ceiling Sail can be hung
up easily.

6. Hang up the sails



Now hang the Ceiling Sail in all four mounted
screw hooks simultaneously.

Cleaning Instructions:

- For plasterboard ceilings, ceiling plugs are required, which are not included in the scope of delivery.
- The load-bearing capacity of the ceiling should be checked before installation.
- We do not provide any guarantee if the ceiling cannot bear the weight.

Care Instructions:

- For dust or small dirt particles, please use a feather duster or vacuum cleaner.
- Light stains can be wiped off with a soft sponge and a little mineral water.
- For moderate soiling, a little upholstery cleaner can also be added to the soft sponge.
- For stubborn stains, apply bleach to a soft sponge and gently rub the sail. Then clean with mineral water.

When selecting the appropriate cleaning agent, ensure that it is colour-neutral (white or transparent). If possible, test the cleaning agent on an inconspicuous area and not on the visible side.

HOFA-Akustik

Phone: +49 7251 3472-400 | **E-Mail:** akustik@hofa.de | hofa-akustik.de

- ▶ **HOFA-Plugins** - Premium plugins for a perfect workflow when producing, mixing, and mastering.
- ▶ **HOFA-College** - The international online academy for audio engineering and music production
- ▶ **HOFA-Media** - Your experienced partner for high-quality CD and pressing.
- ▶ **HOFA-Studios** - Recording, mixing & mastering in one of the most renowned recording studios in Germany.

hofa-plugins.de

hofa-college.de

hofa-media.de

hofa-studios.de

HOFA GmbH

Lusshardtstraße 1 -3, 76689 Karlsdorf | Phone 07251 / 3472 – 0 | Mail office@hofa.de | www.hofa.de/en
Managing Director: Jochen Sachse, Jan Bönisch | District Court Mannheim HRB Nr. 231615