



Mounting Instructions

HOFA Wall Sail with Sawtooth Hangers

Accessory Parts:

Sawtooth Hangers		1 per holder
Small Screw		2 per holder

Mounting Accessories:

Drilling Template:

Ecke außen
corner

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail/ wall sail
Größe 60 / Size60

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail/ wall sail
Größe 120 / Size120

Bohrung Deckensegel
drill hole ceiling sail
Größe 180 / Size180

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail/ wall sail
Größe 60 / Size60

HOFA PureAkust Segel- Montagehilfe
HOFA PureAkust Sail - Assembling aid

Größe 60 / Size60
60 x 120 cm

Größe 120 / Size120
120 x 120 cm

Größe 180 / Size180
180 x 120 cm

Schablone
drilling template

Montageanleitung: www.hofa-akustik.de/montageanleitungen/
Assembly instructions: www.hofa-akustik.de/en/assembly-instructions/

▶ **HOFA-Akustik**

HOFA-Akustik / Lusshardtstraße1-3 / D - 76689 Karlsdorf
+49 7251 3472 400

Ecke außen
corner

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail/ wall sail
Größe 60 / Size60

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail/ wall sail
Größe 120 / Size120

Bohrung Deckensegel
drill hole ceiling sail
Größe 180 / Size180

Bohrung Deckensegel/ Wandsegel
drill hole ceiling sail/ wall sail
Größe 60 / Size60

General Information:



We recommend that two people carry out the installation. Secure fastening and the correct choice of screws and wall plugs always depend on the condition of the wall or ceiling and can only be correctly assessed on site. If in doubt, please consult a tradesperson.



For trouble-free installation, the surface should be as even as possible. Woodchip wallpaper is normally not a problem. On very uneven surfaces, such as natural stone, for example, Installation with the optionally available adjustable telescopic brackets is recommended.




If you have any questions during the installation of the system, please do not hesitate to contact us by phone or e-mail: <https://hofa-akustik.de/kontakt/>

Tools and Equipment Required:

- Drilling machine with drill bit
- Screwdriver with cross bit
- Drilling template HOFA wall sail
- Spirit level/measuring tape
- Depending on the surface (additionally): mounting adhesive for gluing in the dowels


Drilling Template HOFA Wall Sail:

- Depending on the size of the HOFA sail, the template must be rotated and moved. The value can be found on the template.
- Use suitable adhesive material such as strong adhesive tape or adhesive putty to attach the drilling template.
- Assembly is much easier with the help of a second person




Mounting Steps for Installation

1. Position the drilling template




Place the template on the corners of the HOFA wall sail as shown above and mark the drilling points. Repeat the step for the opposite points of the wall sail.

2. Screw the hook onto the sail




Now screw the serrated hooks of the mounting system onto the marked drill points on the wall sail.

3. Attach the template to the wall




With a second person, attach the drilling template to the wall with some tape or adhesive putty. Then mark the first drilling points and draw a guide line at the bottom edge.

4. Rotate the template (Wall Sail 120 cm)



Only for Wall Sail 120: For the drill points on the opposite half, turn the template, attach it to the new position and mark the last drill points.

5. Drilling




Now drill holes and insert suitable dowels.

6. Screw on the wall plate




Screw the wall bracket into the prepared dowel. In some cases, a simple nail is sufficient.

7. Hook in the piton



Now hang the HOFA Wall Sail on the screw using the serrated hooks.



Done! Finally, carefully check the system for stability.

Cleaning Instructions:

- For plasterboard walls, wall plugs are required, which are not included in the scope of delivery.
- The load-bearing capacity of the wall should be checked before installation
We do not provide any guarantee if the wall cannot bear the weight.

Care Instructions:

- For dust or small dirt particles, please use a feather duster or vacuum cleaner.
- Light stains can be wiped off with a soft sponge and a little mineral water.
- For moderate soiling, a little upholstery cleaner can also be added to the soft sponge.
- For stubborn stains, apply bleach to a soft sponge and gently rub the sail. Then clean with mineral water.

When selecting the appropriate cleaning agent, ensure that it is colour-neutral (white or transparent). If possible, test the cleaning agent on an inconspicuous area and not on the visible side.

► HOFA-Akustik

Phone: +49 7251 3472-400 | **Mail:** akustik@hofa.de | hofa-akustik.de

- **HOFA-Plugins** - Premium plugins for a perfect workflow when producing, mixing, and mastering.
- **HOFA-College** - The international online academy for audio engineering and music production.
- **HOFA-Media** - Your experienced partner for high-quality CD and pressing.
- **HOFA-Studios** - Recording, mixing & mastering in one of the most renowned recording studios in Germany

hofa-plugins.de
hofa-college.de
hofa-media.de
hofa-studios.de